

## *Preventive Roof/Rib Outreach Program*

### *PROP THE TOP*



### ***BEST WORK PRACTICES***

- Never work or travel under unsupported roof.
- Know and follow the approved roof control plan at your mine.
- Conduct frequent and thorough work place examinations, especially when adverse conditions are encountered.
- Use the sight, sound, and vibration method to evaluate the roof.
- Scale all loose rock prior to mining and bolting operations.
- Be aware of changing roof, rib, and face conditions and inform other miners of any change.